

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://micronic.nt-rt.ru/> || moc@nt-rt.ru

STARTER PACK BASIC



The Micronic Starter Packs are ideal for research laboratories that want to start using 2D coded tubes, or for those who are not satisfied with their current supplier and would like to try the high quality of Micronic products. Considering the amount of samples, the size of the lab and degree of automation, Micronic offers the Sample Storage Starter Packs in a range of formats: **BASIC**, **STANDARD**, **ADVANCED**, **PREMIUM** and **PREMIUM+**. All the Micronic Starter Packs contain 2D coded tubes with screw or push caps, scanners, and manual or electric (de)cappers.

- *Save up to 20%* compared to buying the products individually
- Enables labs to start storing and sealing up to 4,000 samples
- Available with 0.75ml, 1.00ml, 1.40ml, 3.00ml, 3.50ml or 4.00ml tubes
- Ideal and convenient to different lab sizes and needs
- Class 7 clean-room production
- DNase/RNase and Pyrogene free

COMBINE QUALITY AND LOWER PRICE

The range of Sample Storage Starter Packs enables labs to start securely sealing and storing up to 4,000 samples. Precisely manufactured in a certified Class 7 clean room production environment, a choice of RNase / DNase-free sample storage tubes provides the versatility to suit almost any sample storage requirement.

The Micronic Starter packs are ideal for biobanks, biorepositories or research labs that would like to start using 2D coded tubes for their sample storage. Since Micronic is a world leader in traceable sample preservation and storage, the quality of supplied goods is second to none and the design of all components is optimized to provide top performance.

Starter Pack Basic with Screw Caps contains:

- 10 racks filled with **0.75ml** or **1.40ml** tubes (**internally threaded tubes**)
- Enough **Screw Caps** for capping all 10 racks
- **Micronic Tube Reader DT510** which reads single tube codes in less than 1 second
- **Micronic Tube Reader DT300** handheld device
- Manual Screw Cap Decapping tool

or

- 10 racks filled with **0.75ml** or **1.40ml** tubes (**externally threaded tubes**)
- Enough **Screw Caps** for capping all 10 racks
- **Micronic Tube Reader DT510** which reads single tube codes in less than 1 second
- **Micronic Tube Reader DT300** handheld device
- Manual Screw Cap Decapping tool

Starter Packs Basic with Push Caps contains:

- 10 racks filled with **0.75ml** or **1.40ml** tubes (**internally threaded tubes**)
- Enough **Push Caps** for capping all 10 racks
- **Micronic Tube Reader DT510** which reads single tube codes in less than 1 second
- **Micronic Tube Reader DT300** handheld device
- Manual Push Cap Decapping tool

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://micronic.nt-rt.ru/> || moc@nt-rt.ru