

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://micronic.nt-rt.ru/> || moc@nt-rt.ru

STARTER PACK STANDARD



The Micronic Starter Packs are ideal for research laboratories that want to start using 2D coded tubes, or for those who are not satisfied with their current supplier and would like to try the high quality of Micronic products. Considering the amount of samples, the size of the lab and degree of automation, Micronic offers the Sample Storage Starter Packs in a range of formats: **BASIC**, **STANDARD**, **PREMIUM** and **PREMIUM+**. All the Micronic Starter Packs contain 2D coded tubes with screw or push caps, scanners, and manual or electric (de)capers.

- Save up to 20% compared to buying the products individually
- Enables labs to start storing and sealing up to 4,000 samples
- Available with 0.75ml, 1.00ml, 1.40ml, 3.00ml, 3.50ml or 4.00ml tubes
- Ideal and convenient to different lab sizes and needs
- Class 7 clean-room production
- DNase/RNase and Pyrogene free
- **REQUEST A QUOTE**

EVERYTHING YOU NEED TO GET GOING...

Micronic Starter Packs contain everything needed to start using 2D coded sample storage tubes, enabling laboratory workers to maintain a secure sample logistics system and eliminate the costly possibility of false sample identities. Since the amount of stored samples differs by the extent of automation and laboratory applications, Micronic offers the Starter Packs in a range of configurations and sizes: Basic, Standard, Advanced, Premium and Premium+.

Starter Packs Standard with Screw Caps contains:

- 10 racks filled with **0.75ml** or **1.40ml** tubes (**internally threaded tubes**)
 - Enough **Screw Caps** for capping all 10 racks
 - **Micronic Rack Reader DR505** which reads codes within 5 seconds
 - Manual Screw Cap Decapping tool
- or

- 10 racks filled with **0.75ml** or **1.40ml** tubes (**externally threaded tubes**)
- Enough **Screw Caps** for capping all 10 racks
- **Micronic Rack Reader DR505** which reads codes within 5 seconds
- Manual Screw Cap Decapping tool

Starter Pack Standard with Push Caps contains:

- 10 racks filled with **0.75ml** or **1.40ml** tubes (**internally threaded tubes**)
- Enough **Push Caps** for capping all 10 racks
- **Micronic Rack Reader DR505** which reads codes within 5 seconds
- Manual Push Cap Decapping tool

ORDERING INFORMATION

Standard Starter Packs with Screw Caps

Article Number	Description	Unit Size
MP50225C	0.75ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread V-bottom Starterpack STANDARD consisting of:	
	MP52520 0.75ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread V-bottom in Micronic 96-2 Rack with high cover (Barcoded A1-H1 side)	10 racks
	MP53120 Screw Caps for internally threaded tubes in 96-well format - Grey	960 caps
	MP35221 Micronic Rack Reader DR505	1 unit
	MP54004 Manual Screw Cap remover	1 piece
MP50226C	1.40ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread V-bottom Starterpack STANDARD consisting of:	
	MP52551 1.40ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread V-bottom in Micronic 96-4 Rack with high cover (Barcoded A1-H1 side)	10 racks
	MP53120 Screw Caps for internally threaded tubes in 96-well format - Grey	960 caps
	MP35221 Micronic Rack Reader DR505	1 unit
	MP54004 Manual Screw Cap remover	1 piece
MP50262C	0.75ml 2D Data-Matrix coded Screw Cap tubes with external thread V-bottom Starterpack STANDARD consisting of:	
	MP52706 0.75ml 2D Data-Matrix coded Screw Cap tubes with External Thread V-bottom in Micronic 96-2 Rack with high cover (Barcoded A1-H1 side)	10 racks
	MP53871 Screw Caps IG for externally threaded tubes in 96-well format - Grey	960 caps
	MP35221 Micronic Rack Reader DR505	1 unit

Article Number	Description	Unit Size
	MP54004 Manual Screw Cap remover	1 piece
MP50263C	1.40ml 2D Data-Matrix coded Screw Cap tubes with external thread V-bottom Starterpack STANDARD consisting of:	
	MP52710 1.40ml 2D Data-Matrix coded Screw Cap tubes with External Thread V-bottom in Micronic 96-4 Rack with high cover (Barcoded A1-H1 side)	10 racks
	MP53871 Screw Caps IG for externally threaded tubes in 96-well format - Grey	960 caps
	MP35221 Micronic Rack Reader DR505	1 unit
	MP54004 Manual Screw Cap remover	1 piece

Standard Starter Packs with Push Caps

Article Number	Description	Unit Size
MP50227C	0.75ml 2D Data-Matrix coded Push Cap tubes V-bottom Starterpack STANDARD consisting of:	
	MP52535 0.75ml 2D Data-Matrix coded Push Cap tubes V-bottom in Micronic 96-2 Rack with low cover (Barcoded A1-H1 side)	10 racks
	MP53006 Pierceable TPE Capcluster Grey for capping 96 individual tubes with Internal Thread	10 mats
	MP35221 Micronic Rack Reader DR505	1 unit
	MP54000 Manual Decapper-1	1 piece
	MP54001 Manual Decapper-8	1 piece
MP50228C	1.40ml 2D Data-Matrix coded Push Cap tubes V-bottom Starterpack STANDARD consisting of:	
	MP52554 1.40ml 2D Data-Matrix coded Push Cap tubes V-bottom in Micronic 96-4 Rack with low cover (Barcoded A1-H1 side)	10 racks
	MP53006 Pierceable TPE Capcluster Grey for capping 96 individual tubes with Internal Thread	10 mats
	MP35221 Micronic Rack Reader DR505	1 unit
	MP54000 Manual Decapper-1	1 piece
	MP54001 Manual Decapper-8	1 piece

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://micronic.nt-rt.ru/> || moc@nt-rt.ru