

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://micronic.nt-rt.ru/> || moc@nt-rt.ru

STARTER PACK ADVANCED



The Micronic Starter Packs are ideal for research laboratories that want to start using 2D coded tubes, or for those who are not satisfied with their current supplier and would like to try the high quality of Micronic products. Considering the amount of samples, the size of the lab and degree of automation, Micronic offers the Sample Storage Starter Packs in a range of formats: **BASIC**, **STANDARD**, **PREMIUM** and **PREMIUM+**. All the Micronic Starter Packs contain 2D coded tubes with screw or push caps, scanners, and manual or electric (de)cappers.

- Save up to 20% compared to buying the products individually
- Enables labs to start storing and sealing up to 4,000 samples
- Available with 0.75ml, 1.00ml, 1.40ml, 3.00ml, 3.50ml or 4.00ml tubes
- Ideal and convenient to different lab sizes and needs
- Class 7 clean-room production
- DNase/RNase and Pyrogene free

EVERYTHING YOU NEED TO GET GOING...

Micronic Starter Packs contain everything needed to start using 2D coded sample storage tubes, enabling laboratory workers to maintain a secure sample logistics system and eliminate the costly possibility of false sample identities. Since the amount of stored samples differs by the extent of automation and laboratory applications, Micronic offers the Starter Packs in a range of configurations and sizes: Basic, Standard, Advanced, Premium and Premium+.

Starter Packs Advanced with Screw Caps contains:

- 40 racks filled with **4.00ml** tubes (**internally threaded tubes**)
- Enough **Screw Caps** for capping all 40 racks
- **Micronic Rack Reader DR505** or **Micronic Rack Reader DR710** which reads whole racks filled with 2D Data-Matrix tubes straight from the freezer

- **Micronic Side Barcode Reader**
- or
- 40 racks filled with **1.00ml** or **3.50ml** tissue tubes (**externally threaded tubes**)
- Enough **Screw Caps** for capping all 40 racks
- **Micronic Rack Reader DR505** which reads whole racks filled with 2D Data-Matrix tubes straight from the freezer
- **Micronic Side Barcode Reader**

ORDERING INFORMATION

Advanced Starter Pack with 4.00ml tubes

Article Number	Description	Unit Size
MP50229C	4.00ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread Flat bottom U-bottom Starterpack ADVANCED consisting of:	
	MP52441-Z20 4.00ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread Flat bottom precapped with Grey Screw Cap in Micronic 48-4 Rack with high cover (Barcoded A1-F1 side)	40 racks
	MP35221 Micronic Rack Reader DR505	1 unit
	MP35240 Micronic Side Barcode Reader for DR500 line	1 unit
MP50237C	4.00ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread Flat bottom Starterpack ADVANCED consisting of:	
	MP52441-Z20 4.00ml 2D Data-Matrix coded Screw Cap tubes with Internal Thread Flat bottom precapped with Grey Screw Cap in Micronic 48-4 Rack with high cover (Barcoded A1-F1 side)	
	MP35232 Micronic Rack Reader DR710	
	MP35250 Micronic Side Barcode Reader for DR700 line	

Advanced Starter Pack with tissue tubes

Article Number	Description	Unit Size
MP50230C	3.00ml 2D Data-Matrix coded Screw Cap tubes with External Thread Hybrid Starterpack ADVANCED consisting of:	
	MP52960-Y20 3.00ml 2D Data-Matrix coded Screw Cap tubes with External Thread Hybrid WHR Flat bottom precapped with Grey Screw Cap in Micronic 24-1 Rack with high cover (Barcoded A1-D1 side)	40 racks
	MP35221 Micronic Rack Reader DR505	1 unit
	MP35240 Micronic Side Barcode Reader for DR500 line	1 unit

Article Number	Description	Unit Size
MP50266C	1.00ml 2D Data-Matrix coded Screw Cap tubes Flat bottom Starterpack ADVANCED consisting of:	
	MP52802-Y20 1.00ml 2D Data-Matrix coded Screw Cap tubes with External Thread Flat bottom precapped with Grey Screw Cap in Micronic 48-1 Rack with low cover (Barcoded A1-F1 side)	40 racks
	MP35221 Micronic Rack Reader DR505	1 unit
	MP35240 Micronic Side Barcode Reader for DR500 line	1 unit
MP50267C	3.50ml 2D Data-Matrix coded Screw Cap tubes with external thread Flat bottom Starterpack ADVANCED consisting of:	
	MP52906-Y20 3.50ml 2D Data-Matrix coded Screw Cap tubes with External Thread Flat bottom precapped with Grey Screw Cap in Micronic 24-2 Rack with high cover (Barcoded A1-D1 side)	40 racks
	MP35221 Micronic Rack Reader DR505	1 unit
	MP35240 Micronic Side Barcode Reader for DR500 line	1 unit

Архангельск (8182)63-90-72 Астана (7172)727-132 Астрахань (8512)99-46-04 Барнаул (3852)73-04-60 Белгород (4722)40-23-64 Брянск (4832)59-03-52 Владивосток (423)249-28-31 Волгоград (844)278-03-48 Вологда (8172)26-41-59 Воронеж (473)204-51-73 Екатеринбург (343)384-55-89 Иваново (4932)77-34-06	Ижевск (3412)26-03-58 Иркутск (395)279-98-46 Казань (843)206-01-48 Калининград (4012)72-03-81 Калуга (4842)92-23-67 Кемерово (3842)65-04-62 Киров (8332)68-02-04 Краснодар (861)203-40-90 Красноярск (391)204-63-61 Курск (4712)77-13-04 Липецк (4742)52-20-81	Магнитогорск (3519)55-03-13 Москва (495)268-04-70 Мурманск (8152)59-64-93 Набережные Челны (8552)20-53-41 Нижний Новгород (831)429-08-12 Новокузнецк (3843)20-46-81 Новосибирск (383)227-86-73 Омск (3812)21-46-40 Орел (4862)44-53-42 Оренбург (3532)37-68-04 Пенза (8412)22-31-16	Пермь (342)205-81-47 Ростов-на-Дону (863)308-18-15 Рязань (4912)46-61-64 Самара (846)206-03-16 Санкт-Петербург (812)309-46-40 Саратов (845)249-38-78 Севастополь (8692)22-31-93 Симферополь (3652)67-13-56 Смоленск (4812)29-41-54 Сочи (862)225-72-31 Ставрополь (8652)20-65-13	Сургут (3462)77-98-35 Тверь (4822)63-31-35 Томск (3822)98-41-53 Тула (4872)74-02-29 Тюмень (3452)66-21-18 Ульяновск (8422)24-23-59 Уфа (347)229-48-12 Хабаровск (4212)92-98-04 Челябинск (351)202-03-61 Череповец (8202)49-02-64 Ярославль (4852)69-52-93
Киргизия (996)312-96-26-47	Россия (495)268-04-70	Казахстан (772)734-952-31		

<https://micronic.nt-rt.ru/> || moc@nt-rt.ru